

1. Sit bath in position and ensure all 4 feet are touching the ground. Note: Adjustment can be made to feet by undoing the bolt on the underside of foot and adding or removing a washer. If floor is badly out of level use a grinder with a metal disk to grind foot down to required height.
2. In the bottom of each foot there is a fixing hole. Use a pencil to mark the position for fixing through the locating hole.

For installation on concrete floors

1. Use 6mm x 40mm Dyna bolts, bolted through claw feet into concrete.

For installation on timber floors

2. Use 40mm x 10 gauge tex screws with tex heads, screwed through claw feet into timber floor:

Please note: make sure bath and waste pipe are in correct position, before fixing down. water temperature from the outlet should not exceed 55°C

Cleaning

Warm soapy water or mild household cleaners will be sufficient to remove most marks or residue.

Do not use cleaning products such as, harsh abrasive cleaners, dry cleaning fluids, glass cleaning sprays, or Ammonia compounds. We advise that you refer to any cleaning product warning labels.

Repairs

The baths can only be repaired by an outside source, i.e: Mend a Bath. The external portion of the claw foot baths can be replaced with a fibreglass repair kit. The legs are non repairable, however they can be purchased from Impact Bathrooms.

